puregiene®

Foam Soap Dispenser Instruction (Auto)



How to open dispenser
To open the dispenser,insert key into key holes located at the top/bottom of the dispenser;Pull dispenser cover towards you.



Installation Instruction
Dispenser must be mounted at least 8 inches above any surface.
1. Hold the dispenser against the wall in the desired location, open cover and mark screw hole locations on the wall.
2. Install the provided anchors into drywall and secure the dispenser with the provided screws.



Installing batteries
Open the dispenser, locate the battery compartment on the left side of the dispenser and place four (4) AA-cell Alkaline batteries in the proper orientation and close the cover back into place.



Installing the cartridge:
1. Place the cartridge on top of the control box with the pump facing front and downwards.
2. Then pull the pump downward and clamp into the groove of the control box. Make sure the nozzle of the pump is fixed into the groove of the push rod.
3. Close the dispenser cover. The LED indicator will blink GREEN one time and the dispenser is now ready to be use.
4. Place hand underneath the dispenser, within 5cm of the sensor. The LED will blink GREEN and dispense soap onto your hand.



Sensitivity Automatic Adjustment and Warning:
If the mounting distance is too close to the basin or other obstacles, the LED will blink GREEN and RED by turns to remind of the user to remove the obstacles ahead of the sensor or mount the dispenser higher.

Dosage Option/Reset Counter
1. Press ⏻ to ON/OFF the dispenser.
2. Press ○ to choose the dosage.
   - one dose for every time
   - two doses for every time
   - three doses for every time

The RED LED blink frequently when the voltage is low.
User should press ⏻ to OFF, and then change new batteries , the LED will become normal.

Pump Options
1. **Foam Soap Pump**
2. **Lotion Soap Pump**
3. **Spray Pump**



Cartridge Options
1. Refillable Bottle
2. Disposable pouch